



**Insert SIM**

Do not be alarmed. You have a dual SIM phone with only one SIM inserted. You will always see "Insert SIM" as long as the second SIM tray is empty

**Center Pad**

The edge moves your cursor while in the menu. Pressing the pad is Yes or Enter

**Selection Key**

Selects the option in the bottom right of the screen

**Selection Key**

Selects the option in the bottom left of the screen

**Talk Key**

Send or Answer a call

**Power On/Off - Depress**

**Hang up - Push Once**

**Questions about your Blu Phone?  
Contact Blu customer support at**

**1 (877) 602-8762**